

# Underwater Repair



## Carbon Fiber Composite Repair Solution

for conditions that contain moisture or  
are completely submerged underwater

- Repairs and Upgrades Various Shapes
- Chemical and Corrosion Resistant
- Structural Repair
- Engineered to ASME Standards
- Extends Service Life

## SubSea HYDRAWRAP® INSTALLATION PROCEDURE

### PREPARE SUBSTRATE

using manufacturers recommended procedures.

Measure Fabric around pipe to ensure at least two layers of fabric.

Cut Fabric to desired lengths.



**MIX** both Wet-Out components for two minutes.

**APPLY WET-OUT** to fabric via spreader or impregnator ensuring complete wet out of fabric. Turn fabric over.



**MECHANICALLY MIX** together both primer components until uniform.



**APPLY PRIMER** to opposite side of fabric via brush or spreader.



**APPLY PRIMER SIDE** to substrate ensuring a consistent, smooth wrap free of voids.



**AFTER FIRST WRAP**, gently tug to ensure wrap is tight.



### COMPLETE LINE OF HYDRAWRAP KITS:

Standard HydraWrap

Acid Resistant HydraWrap

Mid-Temp HydraWrap

High-Temp HydraWrap

Marine HydraWrap

Sub-Sea HydraWrap

E-System HydraWrap (Fiberglass Composite)

10448 Chester Road | Cincinnati, OH 45215  
513.827.9169 • [www.hydratechllc.com](http://www.hydratechllc.com)

